



SensoryPEN USER MANUAL

— by Tricia Peterson, BLUERA VEN CREATIVE (BRC)

Self-Recorded or Professionally Recorded Audio

Save each audio clip as a separate file in MP3 (preferred) or WAV format. Blueraven Creative can help with any audio needs. For self-recorded audio, we suggest ordering online the Zoom Handy Recorder with Zoom APH-1n Accessory Pack on Amazon.



Lanyard and Holder

A nylon lanyard, short metal cable and crimps are included with each kit for attaching SensoryPEN to the exhibit. Holders are sold separately and can mount to an exhibit panel, wall or flipbook.



Audio Target Assignment and Audio Linking

Record each audio clip separately and assign a number to each clip. Send the clips in MP3 or WAV format to t@blueravencreative.com. Targets will be compiled, normalized, tested and linked via our proprietary software to each target, and delivered along with your kits, ready to install. Be sure to fully charge the SensoryPEN/s before using. For example . . .



Your Audio Clips

- #1 - Cardinal Alarm Call 01 (pictured)
- #2 - Cardinal Song 02
- and so on . . .

If a target contains 2 or more audio activation areas, assign A or B:

Your Audio Clips

- #1 - English 01 (pictured)
- #1 - Spanish 02 (pictured)



Changing/Updating the Audio on an Existing Targets is EASY

Email the new MP3 or WAV audio clips to t@blueravencreative.com. No need to mail anything. Targets will be compiled, normalized, tested and linked via our proprietary software to each target, and sent electronically for a nominal fee (price depends on complexity and number of targets). Once you receive the .bnl file, with SensoryPEN turned OFF, plug it into your computer with the provided usb cable. Two folders will be inside. Open the E-book folder and replace the existing .bnl file with the new one. The current .bnl can be archived or discarded, but only one .bnl file can be on the SensoryPEN at a time.

Charging

SensoryPEN comes with an internal lithium ion battery, and will hold a charge for 6-8 hours with continued use. To charge, plug the SensoryPEN into any standard outlet with provided cable. Portable chargers can be purchased separately if SensoryPEN's is mounted to an exhibit without an electrical outlet nearby.

Target Application

Apply targets to **smooth, clean, dry** surface. Wipe surface with a 50/50 alcohol/water solution, allow to dry, remove the VHB adhesive and press and hold for 2 minutes. The harder the press, the better the bond. Carefully position the targets. Once placed, they cannot be rotated or adjusted. VHB adhesive sets completely within 72 hours.

SensoryPEN and Target Maintenance

Use a clean cloth dampened with water or a disinfectant wipe for daily/weekly cleaning. Be careful to not allow liquid inside SensoryPEN. Do not use traditional glass window cleaning methods, detergents, or other harsh abrasives.

For additional information, please visit www.sensorypen.com or contact Tricia at 847-226-9115 or t@blueravencreative.com