

# SensoryPEN<sup>®</sup>

BLUERAVERN CREATIVE

## USER MANUAL

### Self-Recorded Audio

Zoom's H1 Handy Recorder with its Accessory Pack work great. Record each audio clip separately and save in MP3 (preferred) or WAV format.

### Professionally Recorded Audio

We offer many actor options, and professional audio studio recording, depending on your needs. Each project is unique and we are here to help.

### Audio Target Assignment and Audio Linking

Send each audio clip to [t@blueravencreative.com](mailto:t@blueravencreative.com). Audio will be compiled, normalized, tested and linked via proprietary software to each target, then delivered for immediate use.

#### Audio Clips

#1 - Cardinal Alarm Call **01** (pictured)  
#2 - Cardinal Song **02**  
and so on . . .



#### Audio Clips

#1 - English **01** (pictured)  
#1 - Spanish **02** (pictured)  
and so on . . .



### SensoryPEN Holder and Metal Lanyard

Holders for mounting SensoryPEN to an interior exhibit, wall or flip-book are available. A nylon lanyard is included with each kit, but vinyl coated lanyards are available for mounting. Metal crimps are provided.



### Revising the Audio on Existing Targets

Email each new MP3 or WAV audio clip to [t@blueravencreative.com](mailto:t@blueravencreative.com). **No need to mail.** Audio clips will be relinked according to your directives, presented for approval and then compiled into a single .bnl file we email to you. With SensoryPEN turned OFF, plug it into your computer with its usb cable and a folder will pop up. Two folders will be inside the main folder. Open the folder labeled "E-book" and **replace** the existing (old) .bnl file with the new one. **Only one .bnl file can reside in the folder.**

### Charging

Fully charge the SensoryPEN/s before first use. SensoryPEN comes with an internal lithium ion battery, and will hold a charge for 6-8 hours with continued use. Charge with provided cable. Portable chargers can be used if outlets aren't available.

### Target Application

Apply targets to **smooth, clean, dry** surface. Wipe surface with a 50/50 alcohol/water solution, allow to dry, remove the VHB adhesive and press target on surface. Carefully position the targets. Once placed, they cannot be rotated or adjusted. VHB adhesive sets completely within 72 hours.

### SensoryPEN and Target Maintenance

Use a clean cloth dampened with water or a disinfectant wipe for daily/weekly cleaning. Do not use traditional cleaners, bleach, detergents, or other harsh abrasives.